


## LCD QUARTZ DIGITAL CLOCK



### OPERATION INSTRUCTION

During normal display, the clock shows HOURS, MINUTES. First push of "B" shows : MONTH DATE . Second push of "B" shows : SECONDS .

### ALTERNATING MODE

Depressing "A" once will activate the Alternating Mode – displaying hours and minutes for a 2 second period , then displaying month and date for 2 seconds, then back again. Return to normal mode requires completion of the setting sequence. See below .

---

### SETTING OPERATION

Upon each depression of the SWITCH "A" , the clock is advanced to the next SET mode in the sequence as follows :- 1. Alternation TIME/DATE display, 2. Set Month, 3. Set Date, 4. Set Hours , 5. Set Minute, 6. Normal Time Display. When desired SET MODE is displayed ,pushing SWITCH "B" will advance the figure to proper time running.